



Selection Guide

Series GRF05 RF Adapters

Precision-grade **Series GRF05 RF Adapters** are used to connect between series or within a series. Frequently used as connector savers, male-female adapters protect RF jacks on instruments from excessive wear-and-tear. 45° and 90° angled SMA male-female adapters provide extra clearance in cramped quarters.



TNC-SMA Adapters

Page 97



TNC Male-SMA Female
GRF05-0015



TNC Female-SMA Female
GRF05-0016



TNC Female-SMA Female,
Square Flange
GRF05-0017



TNC Female-SMA Female,
Jam Nut
GRF05-0018

N-SMA Adapters

Page 98



N Male-SMA Female
GRF05-0019



N Female-SMA Female
GRF05-0020



N Female-SMA Female,
Jam Nut
GRF05-0021



N Female-SMA Female,
Square Flange
GRF05-0022

SMA-SMA Adapters

Page 99, 100



SMA Male-SMA Female
GRF05-0023



SMA Female-SMA Female
GRF05-0024



SMA Female-SMA Female,
Jam Nut
GRF05-0025



SMA Male-SMA Female,
45° Angle
GRF05-0032



SMA Male-SMA Female,
90° Angle
GRF05-0031

2.92-SMA Adapters

Page 101



2.92 Male-SMA Female
GRF05-0026



2.92 Female-SMA Female
GRF05-0027

SMP-SMA Adapters

Page 102



SMP Male-SMA Female
Full Detent
GRF05-0028



SMP Male-SMA Female
Smooth Bore
GRF05-0029



SMP Female-SMA Female
GRF05-0030

BNC-SMA Adapters

Page 102



BNC Male-SMA Female
GRF05-0033